



MILE-TRAK

Information Letter



Mile-Trak is a Texting Service for your iPhone, Android, Smartphone or any other cell phone you might have, and this also includes Free Texting to any Iridium Satellite Phone. Position and tracking information is sent directly to your mobile device, **or Email**.

Mile-Trak is a highly sophisticated product that is easy to use, and was developed by TekNet for use with all the IRC Tracking devices.

Mile-Trak is the product you've all been waiting for. It's time to turn that Smartphone you have into to a really "Super Smart Phone".

Never before has getting the stats on your race vehicle during a race, been so easy.

Now with the Power of Information in the Palm of your Hand,
You'll be the Winner, as well as the Vehicle you're Tracking.

Information Sent to your mobile device will Include :

- Name of the Event
- Driver & Race #
- Time Stamp
- Current Mile Marker Location
- Current Lap for Lap Races
- Speed of the Race Vehicle
- Average Speed of the Vehicle
- Rank Position by Class
- Rank Position - Overall
- Update Rates = 8 or 15 Minute Intervals
- Rank-Mile - Rank will be calculated 12 times in every race.

Free Sample Race Data Sent to Your Phone

Try It Before You Buy It !!

Go to our website RaceTheWorld.net,
Under Products, click Mile-Trak,
Enter Your Information in the
Purple Box and Hit Send.
Enjoy !!

1. The **Time Stamp** is the time when the GPS data is transmitted from the race vehicle, up to satellite to our servers. It takes about 30 seconds for the data to reach our servers.
2. The **Current Mile Marker Location** is the Mile Marker that the race vehicle is closest to at the time of the GPS data transmission. The race vehicle can be up to a half mile ahead of, or behind the Current Mile Marker.
3. The **Speed** of the race vehicle, should be used to calculate the time delay in the transmission of data. Allow about one to three minutes delay in the data reception, overall.
4. The **Rank Position by Class** is calculated by subtracting the Starting Time from the Current Time to give the Elapsed Time. The Elapsed Time is compared to others in your class to give you Rank-Class.
5. The **Rank Position Overall** is calculated the same way except your elapsed time is compared to all the vehicles to give you Rank-Overall.
6. The **Rank-Mile** is where we calculate your Rank Positions. There are 10 Rank Miles in every race, plus the Start and the Finish.
7. The **Update Rates** are decided by you the user at the time of ordering. Not everyone wants their phone going off every 8 minutes, so we offer a 15 minute interval option.

For Pricing Information Please Visit - RaceTheWorld.net | [Products](#) | [Mile-Trak](#)